






## InnoFlue® Appliance Adaptor Quick Guide

InnoFlue® is approved for use on almost all boilers, water heaters, and furnaces. The adaptors below are the most common starter pieces adapting to InnoFlue® (2"-12" diameters) directly off of the appliance.

To find your InnoFlue® starter piece:

1. Scan the QR at bottom and open the InnoFlue® OEM Appliance Adaptor Matrix
2. Locate the appliance to be installed by type (boiler / water heater / furnace)
3. Find corresponding InnoFlue® component by manufacturer and model

### Most Common InnoFlue Starter Pieces

				
<b>No Adaptor</b>	<b>Appliance Adaptor PVC to PPs Long</b>	<b>Appliance Adaptor PVC to PPs w/Gasket</b>	<b>Flanged Appliance Adaptor</b>	<b>Commercial Appliance Adaptor SS to PPs</b>
Appliance takes InnoFlue SW Rigid directly with no adaptor.	Adapts a female PVC/CPVC sized appliance collar (with integrated gasket) to InnoFlue SW Rigid.	Adapts a female PVC/CPVC coupler or appliance flue to InnoFlue SW Rigid.	Adapts to InnoFlue SW Rigid with bolt-down flange.	Adapts a stainless steel appliance flue exhaust (with gasket and clamp) to InnoFlue SW Rigid.



Always refer to appliance I&O manual

**NOTE:** The InnoFlue® parts listed above are the most commonly used adaptors, but several appliances require custom adaptors and additional components. Always refer to OEM Matrix for the specific part numbers necessary to begin your flue gas run.

OEM Matrix



Centrotherm

InnoFlue®  
Polypropylene Vent Systems



UL 1738  
ULC S636